



**Notes**

1. Air-Bloc 07 and Air-Bloc 31 are specifically designed for use when a vapour barrier is placed on the interior. Vapour entering the wall assembly from the warm side is allowed to diffuse through the Air-Bloc membranes.
2. Where large gaps occur in exterior sheathing around brick ties, use Air-Bloc 21 to seal followed by reinforcing tape. Alternatively, use a strip of Blueskin SA extending 75mm (3") around tie and seal all edges with Air-Bloc 21.

Air-Bloc 07 or Air-Bloc 31

**PARAPET DETAIL**

BRICK VENEER / STEEL STUD WALL

Scale: N.T.S.

Plot: 1:5

Issued: 08-14-97

Revision: 06

**AB-18B96**

**BAKOR**

375 Pendant Drive, Unit #2,  
Mississauga, ON L5T 2W9  
10 avenue St. Pierre, Lachine, PQ H8R 1N7