



Notes

1. Blueskin SA or TG can be used as a transition sheet on all Air-Bloc 06, Air-Bloc 21 and Air-Bloc 32 systems as well as all Air-Bloc 07 and Air-Bloc 31 systems.
2. Typical application sequence is to install the Blueskin membrane first, followed by the Air-Bloc liquid membrane.
3. Where large gaps occur in exterior sheathing around brick ties, use Air-Bloc 21 to seal followed by reinforcing tape. Alternatively, use a strip of Blueskin SA extending 75mm (3") around tie and seal all edges with Air-Bloc 21.

Air-Bloc 06, 21 or 32

PARAPET DETAIL

BRICK VENEER / STEEL STUD WALL

Scale: N.T.S.

Plot: 1:5

Issued: 08-14-97

Revision: 06

AB-1B96



375 Pendant Drive, Unit #2,
Mississauga, ON L5T 2W9
10 avenue St. Pierre, Lachine, PQ H8R 1N7