



Notes

1. When Blueskin membranes are used for the air/vapour barrier, the brick tie system can be installed after the Blueskin is installed. This helps assure continuity and significantly reduces installation time.
2. Air-Bloc 21 or 230-21 is applied by notched trowel or gunned in a serpentine pattern to the back of the insulation panels to restrict air movement. Insulation panel joints are also buttered.
3. The transition membrane from the wall to the roof assembly should tie-in to the roof air/vapour barrier to ensure air seal continuity.

Blueskin® SA or Blueskin® TG PARAPET DETAIL BRICK VENEER / STEEL STUD WALL	Scale: N.T.S.	Plot: 1:5	
	Issued: 08-14-97	Revision: 06	
AB-3B96		375 Pendant Drive, Unit #2, Mississauga, ON L5T 2W9 10 avenue St. Pierre, Lachine, PQ H8R 1N7	