



**Notes**

1. Blueskin SA is self-sealing when self-taping fastening systems are used.
2. The transition membrane from the wall to the roof assembly should tie-in to the roof air/vapour barrier to ensure air seal continuity.
3. It is recommend that a pre-start meeting be held between general contractor and subtrades to co-ordinate application of the membrane and transition membranes at wall-to-roof, wall-to-window and the junction of dissimilar materials, etc.
4. Apply Blueskin membranes in shingle fashion whenever possible.

Blueskin® SA or Blueskin® TG

Scale: N.T.S.

Plot: 1:5

**PARAPET DETAIL**

Issued: 08-14-97

Revision: 06

BRICK VENEER / CONC. BLK. WALL

**AB-4B96**

**BAKOR**

375 Pendant Drive, Unit #2,  
Mississauga, ON L5T 2W9  
10 avenue St. Pierre, Lachine, PQ H8R 1N7