



Brick Veneer
Air Space
Insulation
Blueskin® SA or TG
Concrete Masonry Unit
Furring
Gypsum Board

Seal termination of
TWF with Air-Bloc 21

Air-Bloc 21

Blueskin® TWF
Thru-Wall Flashing
Sheet

Blueskin® SA or TG

Notes

1. It is recommended that the Insulation be sealed around the perimeter and adhered to the air/vapour barrier with Air-Bloc 21.
2. When Blueskin membranes are used for the air/vapour barrier, the brick tie system can be installed after the Blueskin is installed. This helps ensure continuity and significantly reduces installation time.
3. When the brick-tie system is installed prior to the Blueskin, the membrane is cut, fitted and sealed with Air-Bloc 21 around each tie projection. A 50mm(2") lap is needed over the ties.

Blueskin® SA or Blueskin® TG

SHELF ANGLE DETAIL

BRICK VENEER / CONC. BLK. WALL

Scale: N.T.S.

Plot: 1:5

Issued: 08-14-97

Revision: 06

AB-8B96

BAKOR

375 Pendant Drive, Unit #2,
Mississauga, ON L5T 2W9
10 avenue St. Pierre, Lachine, PQ H8R 1N7