



Notes:

1. Treat inside and outside corners of sheathing boards with a strip of BlueskinVP™ self adhered water resistive air barrier membrane extending a minimum of 3 inches on either side of the corner detail.
2. Pretreat inside corners with a 1/2 inch bead of Henry HE925 BES Sealant.
3. Ensure minimum of 2 inch overlap at all side laps and 3 inch overlap at all end laps. Roll all laps with counter top roller.
4. Apply BlueskinVP™ self-adhered weather resistive air barrier membrane complete and continuous to substrate in a sequential overlapping weatherboard method starting at bottom of wall and working up.
5. Refer to Henry BlueskinVP™ Installation Guidelines for recommended installation procedures.



BLUESKINVP™ SELF ADHERED AIR BARRIER

SCALE: N.T.S.

EXTERIOR SHEATHING

9-12-09

CORNER  
DETAILS

AB-H213