



Notes:

1. Detail shows BlueskinVP™ self-adhered water resistive air barrier system installed over exterior grade sheathing or CMU. Other acceptable substrates include DensGlass Gold®, plywood, OSB, concrete and concrete block.
2. Clean dry sheathing boards do not typically require a primer. Concrete and concrete block substrates are required to be primed prior to application of BlueskinVP™ self-adhered water resistive air barrier membrane.
3. BlueskinVP™ self-adhered water resistive air barrier system shall be installed so as to provide a continuous barrier to prevent air and water intrusion.
4. Penetrations of the air barrier system shall be sealed with Henry HE925 BES Sealant to maintain the integrity of the air barrier system over the entire surface.
5. Refer to Henry BlueskinVP™ Installation Guidelines for recommended installation procedures.

Henry
 COMPANY®
 www.henry.com

BLUESKINVP™ SELF ADHERED AIR BARRIER

SCALE: N.T.S.

BRICK VENEER / STEEL STUD

9-12-09

**COLUMN
 DETAIL**

AB-H214