



Notes

1. Termination detail may also be a reglet/ counter flashing.
2. Seal all terminations with Polybitume 570-05 or Elasto-Seal LM if not covered on same day by field membrane.
3. A termination bar must be used on all deck-to wall expansion joint details.
4. See Technical Data Sheets for requirements of membrane protection.

Blueskin® WP 200

EXPANSION JOINTS

SELF-ADHERED WATERPROOFING SYSTEM

Scale: N.T.S.

Plot: 1:5

Issued: 02-14-98

Revision: 03

ES-8B98

BAKOR

375 Pendant Drive, Unit #2,
Mississauga, ON L5T 2W9
10 avenue St. Pierre, Lachine, PQ H8R 1N7